

Trim Complete: Expert Advice from Start to Finish

Table of Contents

Before You Start.....	2
About Your Safety.....	4

SELECTING TRIM & MATERIALS.....	6
------------------------------------	---

Trim Styles

Choosing a Style.....	8
Moldings.....	10

Materials

Lumber and Sheet Goods.....	12
Synthetic Trim.....	13
Glues.....	14
Fasteners.....	15

TOOLS & TECHNIQUES.....	16
-------------------------	----

Power Saws

Power Miter Saw.....	18
Circular Saw.....	23
Tablesaw.....	26
Jigsaw.....	31

Portable Power Tools

Router.....	33
Cordless Drill Driver.....	36
Biscuit Joiner.....	38
Planers.....	39
Nail Guns.....	40
Sanders.....	41

Hand Tools & Accessories

Handsaws.....	42
Chisels and Planes.....	45
Pounding and Prying Tools.....	46

Marking & Measuring Tools

Rules and Tapes.....	47
----------------------	----

Squares.....	47
Levels.....	48

Other Tool Techniques

Removing Old Trim.....	51
Making Back Cuts.....	52

WINDOWS.....	54
--------------	----

Jambs

Adjusting Walls and Jambs.....	58
Starting with a “Jamb” Session.....	59
Making Jamb Extensions.....	60
Installing Shimmed Jambs.....	61
Making and Installing Rabbeted Jambs.....	62

Window Stools & Aprons

Making a Window Stool.....	64
Scribing Stool Horns.....	66
Mitered Return on an Apron.....	67
Stool with Drywalled Jamb.....	68

Window Casing

Making Mitered Window Casing.....	70
Pre-Assembling a Mitered Casing.....	73

Windows in a Series

Stool for Windows in a Series.....	74
Installing Mitered Mullions.....	76
Installing Flat Mullions.....	78

Windows with Style

Installing Craftsman-Style Trim.....	79
Installing Arts and Crafts-Style Trim..	80
Installing Trim with Rosettes.....	82
Perimeter Molding and Back Banding..	84

DOORS.....	86
------------	----

Installation

Preparing the Rough Opening.....	90
Setting a Swing Door.....	91
Installing a Prehung Single Door.....	92

Installing Prehung French Doors.....	94
Installing a Pocket Door.....	96
Installing Jambs on a Pocket Door....	98
Installing Bifold Doors.....	100

Making Adjustments

Cutting Doors to Length.....	102
Trimming a Hollow Core Door to Length.....	103
Cutting Doorjambs to Length in Place.....	104
Correcting a Hinge-Bound Door.....	105

Casing & Trim

Prepping the Wall and Door Frame...106	
Casing with Mitered Trim.....	107
Craftsman-Style Casing.....	109
Traditional Casing with Parting Bead.....	110
Casing with Rosettes and Plinth Blocks.....	112
Rabbeted Banding.....	113

RUNNING MOLDINGS.....114

Baseboard Molding

Installing Baseboard around 90-Degree Corners.....	119
Installing Baseboard around Radiused Corners.....	120
Coping Inside Corners.....	121
Installing Corner Blocks.....	122
Splicing Baseboards.....	123
Scribing Baseboard to the Floor.....	124
Installing Moldings on Uneven Walls.....	125
Transitioning Moldings.....	126
Running Baseboard to Stair Skirtboards.....	127

Crown Molding

Crown Molding on a 90-Degree Corner.....	128
Crown Molding on a Radiused Corner.....	130

Coping Inside Corners.....	131
Cutting Crown in Position on a Miter Saw.....	132
Cutting Crown Flat on a Compound Miter Saw.....	133
Splicing Crown on the Wall.....	136
Splicing Crown Using Backer.....	137

Wall Cap

Installing Wall Cap.....	138
Mitered End Cap.....	140

Perimeter Band Boards

Installing Perimeter Band Boards.....	142
---------------------------------------	-----

WAINSCOT.....144

Tongue-and-Groove Wainscot

Making Rabbeted Baseboards.....	148
Installing Rabbeted Baseboards.....	149
Installing Tongue-and-Groove Boards.....	151
Installing a Closing Board to an Irregular Wall.....	153
Marking and Cutting for Outlets.....	154

Installing Chair Rail

Installing Wainscot Cap.....	155
Installing Rabbeted Cap.....	156
Installing Chair Rail at 90-Degree Corners.....	157
Installing Cap on Radiused Outside Corners.....	158

Pre-Assembled Frame-and-Panel Wainscot

Laying Out Frame-and-Panel Wainscot.....	160
Assembling the Frame-and-Panel Unit.....	162
Locating and Cutting Holes for Outlets.....	164
Installing Frame-and-Panel Assembly to Wall.....	165

Installing Assembled Panels on 90-Degree Corners.....	168
Assembled Panels around a Bullnosed Corner.....	168
Frame-Over-Panel	
Pre-Assembled Frame-Over-Panel...	169
Installing Frames Piece by Piece.....	172
Pre-Assembled Frames and Precut Panel	
Installing Pre-Assembled Frame and Precut Panels.....	174
CEILING ELEMENTS.....	176
Tongue-and-Groove	
Fitting Starting Boards on a Flat Ceiling.....	179
Fitting Starting Boards on a Raked Ceiling.....	180
Pulling together Stubborn Tongue-and-Groove.....	181
Cutting Out for a Ceiling Fixture.....	182
Fitting an Angled Ceiling Break.....	184
Installing a Closing Board.....	186
Paneled Ceiling	
Locating Ceiling Joists and Layout...	188
Cutting Out for Fixture in a Paneled Ceiling.....	189
Installing Plywood Panels.....	190
Coffered Ceiling	
Installing Trim Boards on a Ceiling...	192
Installing Ceiling Panel Trim Moldings.....	194
Installing Pre-Assembled Panel Moldings.....	196
Exposed Beams	
Installing Beam Nailers.....	198
Attaching Beam Nailers with Butterfly Bolts.....	199
Faux Beam over Hollow Nailers.....	200

Faux Beam over Solid Nailers.....	202
-----------------------------------	-----

Faux Posts

Trimming a Freestanding Post.....	204
Faux Post with Corner Moldings.....	205

ADVANCED TECHNIQUES & PROJECTS.....	206
-------------------------------------	-----

Custom Moldings

Combining Moldings.....	208
Simple Molding on the Router Table.	209
Built-Up Molding.....	210
Complex Molding with Multiple Bits.....	212
Making Dentil Moldings.....	213
Back Band and Casing Combination.	214
Fluting with a Router.....	215
Cutting Coves on the Tablesaw.....	216

Radiused Moldings

Bending Millwork.....	218
Laminating a Curved Molding.....	219
Kerf Bending a Curved Molding.....	220
Steam Bending a Curved Molding...	222

Advanced Projects

Frame-and-Panel Faux Post.....	224
Installing Build-Up Crown Molding.	226
Fireplace Surround and Mantel.....	228

Glossary.....	230
Index.....	232